


# SATELLINE-3AS(d) (NMS) (YM1011, YM1016, YM1070, YM1075)

Needed hardware for accessing the programming menu via RS-232 interface



\* YC0200; NARS-1F; Interface adapter (D15male / D9female)

\* YC0201; CRS-9; Direct serial interface cable (D9male / D9female)

(\* Power supply +9...+30V)